

Hold Mode 7 seconds

Scroll down to Initialize

Initialize YES

Select Output (PHP)
Flow Direction (FROM CABLE SIDE)
Pipe Material (PLASTIC)
Pipe Size (3/8")
Resolution Mode (STANDARD L)
Quick Setting (OFF)
End Config

Basic Setting

Output 1 Mode (PULSE +)
Output 1 Logic (N.O.)
Output 2 Mode (PULSE -)
Output 2 Logic (N.O.)
Select Analog (4-20ma)
Analog Scaling (4ma = 0.00)
Analog Scaling (20ma = 20.00)
Input 1 Function (OFF)
Input 2 Function (OFF)
Response Time (500ms)
Int Flow Unit (0.01)
Menu (FULL)

ADVANCED SETTING

Flow Resolution (0.001)
Dip Average (1.0s)
Zero Cut Flow (0.100)
Head LED (GREEN)
Brightness (30%)
Password Lock (OFF)
Flow Direction (FROM CABLE SIDE)
Pipe Direction (3/8")
Pipe Size (OFF)

Save Configuration